


# ILIFE-V9 Pro

Robotic vacuum cleaner

## User Manual



For more detailed information,  
please visit: [www.iliferobot.com](http://www.iliferobot.com)

**ILIFE**



Dear Customer,

Thank you for purchasing the ILIFE V9 Pro Robotic Vacuum Cleaner! You've joined the millions of people cleaning with robots - the smartest way to do it.

Please take a few moments to read through this manual and familiarize yourself with your robot to achieve the best performance. If you encounter any issues with your robot, feel free to contact our customer service or visit our website at [www.iliferobot.com](http://www.iliferobot.com) for further assistance. Stay connected with us on "X" to enjoy these exclusive benefits:

- Get tailored support for your specific robot, including answers to your questions, maintenance tips, video demonstrations, live chat, and more.
- Receive product updates and other valuable information, be among the first to discover new robots, exclusive discounts, and special promotions.

Connect with us now on  
X: [https://x.com/ilife\\_Global](https://x.com/ilife_Global)

Enjoy comprehensive cleaning every day! Best regards,  
ILIFE Innovation

## ILIFE Customer Service



[service\\_asia@iliferobot.com](mailto:service_asia@iliferobot.com) (Asia)

[service\\_au@iliferobot.com](mailto:service_au@iliferobot.com) (Australia)

## Table of Contents

<b>Safety Instructions</b> .....	3
<b>Product Composition</b> .....	5
List of accessories .....	5
Host introduction .....	6
Robot anatomy .....	7
Self-empty station .....	8
2-in-1 dustbin and water tank .....	9
Remote Control .....	9
<b>Product Specifications</b> .....	11
<b>Product Operating</b> .....	12
Attentions .....	12
Quick guide .....	14
Select cleaning modes .....	18
Water tank operation .....	19
<b>APP Connection</b> .....	21
<b>Maintenance</b> .....	24
Clean up dustbin and filters .....	24
Cleaning of water tank components .....	25
Replacing the dust bag .....	26
Cleaning the dust passage .....	26
Clean up the side brushes .....	27
Check side wheels .....	27
Other spare parts .....	27
<b>Troubleshooting</b> .....	29
Error codes .....	29

## Safety Instructions

---

### Warnings

1. This robot should not be used by children under 8 or people with mentally challenged, unless they are under supervision. Do not let children sit on the robot or use it as a toy.
2. Attend to the robot promptly if an error occurs during cleaning. Before using the robot, remove all power cords and small objects on the floor. Roll up carpet tassels and make sure curtains and table cloth are not in contact with the floor.
3. If there are hanging steps or stairs, please test if the robot can detect them before use. If not, please set up barriers to avoid falling down, and make sure that the barriers cause no harm to people.
4. Follow the instructions in this user manual. Use factory authorized or recommended accessories only.
5. Make sure the voltage of the charging dock is compatible with the voltage of power supply.
6. Use the robot indoor and in a home environment only. Do not use it outdoor, or in commercial or industrial spaces.
7. Use factory authorized adaptor and charging dock only. Do not use non-rechargeable battery. Refer to "Product Specifications" section for details about battery standards.
8. Do not soak the robot in water and do not rinse the robot under the faucet.
9. Do not clean the robot with dripping wet cloth.
10. Do not use the robot on floors with ponding water.
11. Do not use the robot near fire or fragile objects.
12. Do not make the cloth, humans hair, finger, or other parts of the body close to the open or the running mechanism of the robot.
13. Do not use the robot on floors with stones or paper to avoid being stuck.
14. Do not use the robot in areas with any flammables, such as gasoline, toner and so on. Or use the robot to clean any burning objects, like cigarettes, ashes or matches, or anything that may cause a fire.
15. Do not use damaged charging dock.
16. Do not lift up the robot or the charging dock by the power cord, and keep the power cords away from heat and avoid it being trapped around doors, sharp edges or corners.

## Safety Instructions


---

17. Damaged power cords must be repaired by manufacturer's repair service or certified technicians.
18. Install dustbin and filters properly before using the robot.
19. Do not use the robot in rooms where babies are sleeping.
20. Do not use damaged power cords or charging dock to recharge the robot.  
Do not use the robot if it's damaged by falling down, or soaking in water.
21. Turn off the power switch if the robot will not be used for a long time.
22. Turn off the power switch before cleaning or maintaining the robot.
23. Unplug power cords from the charging dock before cleaning or maintaining the robot.
24. Remove battery before discarding the robot.
25. Robot and battery are to be disposed of according to local safety regulations.
26. Do not cremate the robot to avoid the explosion.
27. This equipment should be installed and operated with a minimum distance of 20cm between the antenna and your body.
28. Frequency bands: Bluetooth 2402-2480 MHz, Wi-Fi 2412-2472 MHz.
29. Maximum radio-frequency power transmitted: Bluetooth <10dbm (EIRP), Wi-Fi <20dbm (EIRP).
30. Follow the instructions in this user manual.  
Manufacturer is not responsible for any damages caused by improper use.


## Product Composition

---


### List of accessories



Main body




Self-empty station



Dust bag X5




Remote Control



Mopping support



Mop cloth



Extra side brush X2




User manual



AAA Battery X2

Product Composition

Host introduction




Button	Robot status	Operation	Functional description
Auto Button	Turn off	Press and hold for 2 seconds	Turn on the robot
	Turn on	Press the button once	Start/Stop cleaning
		Press and hold for 3 seconds	Turn off the robot

Power indicator	Green	Electricity $\geq 15\%$
	Orange	Electricity $\leq 15\%$
	Red	Failure or abnormality




## Product Composition

### Robot anatomy



Product Composition


Self-empty station



Power indicator light	Green	Solid on - Robot vacuum fully charged
		Breathing - Self-emptying station powered on
	Red	Flashing - Dust bag not installed
	Orange	Flashing - Self-emptying station starting to collect dust
		Breathing - Charging in progress
	Off	Sleep mode

## Product Composition


### 2-in-1 dustbin and water tank



#### Note:

When the water tank is filled with water, the robot's ability to overcome obstacles and climb hills may be affected.

### Remote Control



## Product Composition

### 1 Clean/Pause button

- Press the button to switch the robot from sleep mode to idle mode.
- Press the button when in idle mode to start cleaning.
- Press the button to Pause the robot during its operation.

### 2 Direction buttons

#### A. “^” Forward

Press the button to move the robot forward.

#### B. “✱” Adjustable suction/water volume button

Press the button to switch suction in working mode, and press this button to switch water flow in mopping mode.

#### C. “<” Left

Press the button and the robot will turn left.

#### D. “>” Right

Press the button and the robot will turn right.



**Note:** “^” cannot be used during a cleaning cycle.

### 3 Auto charge button

Press the button and the robot will return to the charging dock for recharging.

### 4 Edge cleaning button

Press the button to start border cleaning.

### 5 Spot mode button

Press the button to start the spot cleaning.

### 6 Path mode

Press the button to start cleaning under path mode.

### 7 MAX mode

During the cleaning process, if there is a lot of dust, press this button to increase the suction power of the robot. Press it again to switch to the max suction power, press it again to switch to the mute mode suction, and press it again to switch back to auto mode suction.



**Note:**

Please install two AAA/R03 batteries before using the remote control.  
Please take out the batteries if the remote control won't be used for a long time.

## Product specifications

### Main unit

Overall dimension	315x315x79mm
Net weight	2.25kg
Battery type	Li-ion
Charging time	<300mins
Capacity of dustbin	0.2L
Capacity of water tank	0.2L

### Self-empty station

Overall dimension	285x145x253mm
Net weight	2.0kg
Rated Input	220-240V~50/60Hz
Rated Output	19V $\approx$ 0.6A
Dust bag capacity	2.5L




**Note:**

The company reserves the right of final decision on the interpretation of these terms and conditions.


## Product Operation

### Attentions


The robot may skip over some areas due to the complexity of the home environment. To achieve the best result, we suggest using it as daily routine and clearing up the obstructions on the floor before starting the robot.



Please move away the power cords and other objects that may tangle the robot before cleaning.




Please fold up the edges of the carpets before cleaning.




To avoid being stuck during cleaning, please arrange the furniture neatly.

## Product Operation

### Attentions



Please do not stand at somewhere with narrow space like the door sill or hallway in case of blocking the robot and skipping over some areas.




Please do not stand by downstairs when the robot is working upstairs in case of getting injured by any fallen objects.

## Product Operation

### Quick guide

#### 1 Self-emptying station installation


- Place the self-emptying station on a hard surface against the wall, plug in the power cord, and turn on the power.
- Ensure there are no obstacles within approximately 1.5 meters in front of and 0.5 meters above the self-emptying station's infrared signal range. Avoid strong reflective objects like mirrors and direct sunlight.
- Install the dust bag and close the lid. The self-emptying station indicator light will breathe, indicating it's in standby mode.



**Reminder:** After powering on the self-emptying station, the indicator light will stay solid.

#### 2 Turn on the robot

- Press and hold the AUTO button for 2 seconds to turn on, and press and hold it for 3 seconds to turn off.



**Note:**


- After the robot finishes its work, please do not turn it off, and fully recharge it for the next run.
- If the robot pauses working for more than ten minutes, it will enter sleeping mode. If you need to wake up the robot again, you need to press the AUTO button once.



## Product Operation

### 3 Robot charging

1. Place the robot unit on the self-emptying station, aligning it with the charging electrodes.
2. During charging, the AUTO button will breathe orange; after charging is complete, all lights will turn off.
3. Charge for 6 hours for the first time.




#### Reminder:

1. Please keep the charging pins clean in daily use to ensure a good connection.
2. For daily use, place the robot on the self-emptying station and ensure the self-emptying station is powered on. (Placing it on the self-emptying station will automatically turn it on.)
3. If you won't use the robot for a long time, please fully charge it, turn off the power and keep it in a well-ventilated dry place.

### 4 Automatic dust collection by self-emptying station

- When the charging contacts of the self-emptying station come into contact with the robot vacuum and begin charging, wait for 3 seconds to start the dust collection mode. The fan will run for 15 seconds, and the self-emptying station indicator light will flash orange.
- The dust collection will only occur when the robot has cleaned for more than 20 minutes and returned to recharge. (The app can be set to schedule a return to charge and dust collection after running the machine randomly three times, each time for more than 20 minutes.)





#### Note:

If the machine has a mop bracket installed, dust collection function will not be executed.

## Product Operation

### 5 Start cleaning

After waking up the robot, you can press the AUTO button once, and the robot will start the automatic cleaning.




- \* Before starting cleaning, you need to make sure the indicator light is flashing and the robot is in a wake-up state. If the robot is sleeping, please press the AUTO button once to wake up the robot.
  - \* If you want to choose other modes, please operate on the APP.
  - \* The robot performs path planning autonomously during the working process. If it is manually moved or operated by the APP (except pause), the robot will re-plan the path and may re-clean the cleaned area.
- To ensure the working efficiency of the robot, please do not manipulate the robot. (If the machine is lifted, it will alarm and stop cleaning, and you need to press the AUTO button or operate the APP to restart cleaning)

## Product Operation

### 6 Pause

When the robot is working, you can pause the robot by pressing the robot's AUTO button or the "standby" button in the APP.




#### Reminder:

1. The Robot will automatically enter the Sleep Mode if no action is taken for 10 minutes. If you want to start the robot again, please press the AUTO button once to wake up the robot.
2. The robot will work out a new cleaning path, and will clean the areas again which have been cleaned before.

Note: After the sleeping robot in pause mode is woken up again, it needs to be restarted to start cleaning, and the robot will not resume the last unfinished cleaning.

### 7 Sleep mode

- The Robot will automatically enter the Sleep Mode if no action is taken for 10 minutes.




## Product Operation

### Select cleaning modes

To accommodate different floor types and ensure thorough cleaning, this product provides multiple cleaning modes, which can be selected using the remote control or the companion APP.


#### 1 Auto charge

The robot can sense lower power during the cleaning process and automatically activate Self-charge Mode and search for the charging dock.




#### 2 Spot mode

This mode is suitable for the ground environment where garbage is more concentrated. In this mode, the robot can carry out concentrated cleaning in a "spiral" route in a designated area.



#### 3 Edge Mode

This mode is mainly for cleaning indoor corners. In this mode, this robot can clean along the edge of fixed objects (such as walls).



## Product Operation

### Water tank operation

The water tank with a mopping cloth is installed into the device. Please kindly add water to the water tank before mopping. It is recommended to vacuum the floor before mopping. For daily maintenance, please check out the tips on the corresponding chapter in this manual.




**Note:**

1. Please do not use water tank components on the carpet .
2. Please pay attention during the mopping mode, timely add water or clean the mopping pad. The water tank needs to be removed when adding water.
3. Be sure to remove the water tank components when charging.


#### ① Remove the water tank components

Slide back to remove the water tank components.



#### ② Add water


Open the water injection cap and fill it with water. Tightly close the cap once finish water injecting.



## Product Operation


### ③ Place the mopping support

Paste a mopping support.



### ④ Install water tank components

Slide it forward, align it with the clip, and when you hear a "click" sound, it is installed in place, and then you can press the sweep button to automatically execute the corresponding mopping mode.



## APP Connection



1. The robot can be controlled by the "ILIFEHOME" App. Scan the QR code to install the App on your iOS or Android device. Or search "ILIFEHOME" in the mobile App store to download the App.



ILIFEHOME



ILIFEHOME



2. Register and log into the App.

3. Select your device model.


## APP Connection

### 4. Two methods available to add the device into the App.

#### Bluetooth ⇄

Enable Bluetooth on Your Phone:

To connect via Bluetooth, please ensure that Bluetooth is enabled on your phone.




#### Pairing Process:

Go to setting in the phone and enable Bluetooth >

Back to App and the device will pop up on the top and click Add >

Select home 2.4GHz wifi and enter password > Download and finish.







## APP Connection

### AP Mode ⇐


Firstly start the robot by clicking the AUTO button, press and hold the AUTO button for 6 seconds, the WiFi indicator light flashes slowly, it means that the machine has entered the networking mode.




Go to phone's setting and select the robot's hotspot starting with "adh\_xxx", and after connecting successfully, return to the App.



Select a 2.4GHz Wi-Fi network and enter the password.







Connecting device is processing. Please wait until finished.



## Maintenance

### Clean up dustbin and filters

\* Please turn off the robot before cleaning any spare parts, and remember to cut off the power.




1. Open the cover, take out the dustbin and high-performance filter, and press the button on the dustbin to release all dust, then wipe clean the dustbin.
2. Take out the high-performance filter. Slightly tap it to empty the trash in it.


## Maintenance

### Cleaning of water tank components

#### ① Clean the mop cloth




Remove: after mopping, please remove the water tank components and the mop cloth.




Maintenance: rinse and air dry the mop cloth.

#### ② Clean the water tank



Remove: after mopping, remove the mop cloth and the components, drain the remaining water in the water tank.




Maintenance: dry the water tank by hand and then air dry it.


## Maintenance

### Replacing the dust bag


Open the top cover of the dust charging base, remove the dust bag, dispose of it in the trash, take out a new dust bag, check for any damage, place it in the dust bag slot, and cover it with the lid.



Open the top cover of the base station.



Remove the dust bag and discard it.




Replace with a new dust bag and cover the top of the station.

- \* Damaged dust bags may cause damage to the self-emptying station. Before use, check if the dust bag is intact.
- \* Dust bags are disposable consumables with a usage cycle of about one and a half months. Please check and replace them regularly to avoid damage caused by prolonged use.
- \* If dirt accumulates in the dust bag compartment of the self-emptying station, it is recommended to clean it regularly to ensure the filter is free of foreign objects, avoiding blockage of the fan inlet and affecting performance.

### Cleaning the dust passage

If any foreign objects are found blocking the passage, unplug the power plug, turn over the self-emptying station, and refer to the diagram below. Use a screwdriver to remove the transparent cover of the dust passage and clean out the foreign objects.





- \* Do not disassemble violently. After cleaning, reinstall it as it was.

## Maintenance


### Clean up the side brushes

- Remove side brushes. Wipe clean with a clean cloth.
- When replacing the side brush, please distinguish the corresponding installation position of the "L" "R" side brush.




### Check side wheels

When a buzzer sounds, turn off the power, and then clear any objects blocking the side wheels.




### Other spare parts



Please turn off the robot first, then pull out the nose wheel vertically, clean off the hair and foreign objects tangled in the nose wheel, and wipe it with a clean cleaning cloth.



## Maintenance



Periodically wipe the sensor with a dry cloth to keep it clean.



Clean the charging pins on the robot and the charging dock regularly with dry cloth.

- \* When the battery is in the depth of discharge state or not in use for a long time, its capacity will be reduced. In this case, we suggest you to activate it again. Charge the robot on the charging dock for 3mins, and repeat 3 times, then fully charge the robot for 5-6hours.
- \* The robot uses long cyclic life batteries. There is no need to replace it frequently. Please contact our support team if necessary.

## Troubleshooting

### Error codes

The robot will remind you by beeping when it is malfunctioning.

• Short tones

NO.	Tone	Possible Cause	What to do
01	•	Wheels or side brushes or fan problems.	check and clean wheels, side brushes, and fans.
02	• •	OBS or bumper sensor or cliff sensor failure.	Check the bumper and OBS, and clean cliff sensor.
03	• • •	Robot gets stuck.	Move the robot.
04	• • • •	Gyro failure.	Move the robot.



**Note:**

If the solutions above don't resolve the issue, please try the following:

1. First, press and hold the AUTO button for 3 seconds to turn off the robot , then press and hold the AUTO button for 2 seconds to turn on the robot.
2. If restarting the robot still does not solve the problem, please send the machine to the after-sales center for repair.

